



PIPE 6" OR LESS DIAMETER
 USE SNIPS TO MODIFY ECORAIN TANK
 LARGE PLATE ONLY TO MATCH PIPE
 DIAMETER, PLACE PIPE/INSPECTION
 PORT TO AVOID CONFLICT WITH
 INTERNAL PLATES. DO NOT CUT HOLE
 LARGER THAN PIPE DIAMETER.




PIPE 8" DIAMETER AND LARGER
 DO NOT CUT HOLE IN TANK

CUT 'X' THROUGH GEOTEXTILE AND
 IMPERMEABLE MEMBRANE IF INCLUDED
 THEN APPLY GEOTEXTILE COLLAR TO
 SECURE FABRIC AND PREVENT SAND,
 SOIL OR DEBRIS FROM ENTERING THE
 SYSTEM, SEE FRONT ELEVATION BELOW



IMPORTANT - ALL WATER ENTERING THE
 ECORAIN TANK SYSTEM MUST BE
 FILTERED EITHER THROUGH SOIL OR
 FILTER, DO NOT CONNECT PIPE WITH
 UNFILTERED WATER DIRECTLY INTO
 ECORAIN TANK SYSTEM.

INSTALL ONE LAYER ET-140 | ECOVOID™
 HD 2" CELL AGAINST ECORAIN TANK
 FACE, MODIFY SECOND ET-140 |
 ECOVOID™ HD 2" CELL FOR PIPE
 DIAMETER AND INSTALL AGAINST
 FIRST ECOVOID™ CELL AND
 INSERT PIPE



CONCEPT LARGE AND SMALL DIAMETER PIPE CONNECTIONS

NOTE:
 SEE ET-1214 FOR ADDITIONAL INFORMATION